Please read and save these instructions. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference.

Need Assistance? Call Us First! 1-800-543-8622

CAMPBELL HAUSFELD™ BUILT TO LAST

Oilless Air Compressors

Description

Oilless compressors are designed for do-it-yourselfers with a variety of home and automotive jobs. These compressors power spray guns, impact wrenches and other tools. These units operate without oil.

Safety Guidelines

This manual contains information that is very important to know and understand. This information is provided for SAFETY and to PREVENT EQUIPMENT PROBLEMS. To help recognize this information, observe the following symbols.

⚠DANGER ***Danger indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.***

⚠WARNING ***Warning indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.***

⚠CAUTION ***Caution indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.***

⚠NOTICE ***Notice indicates important information, that if not followed, MAY cause damage to equipment.***

Unpacking

After unpacking the unit, inspect carefully for any damage that may have occurred during transit. Make sure to tighten fittings, bolts, etc., before putting unit into service. In case of questions, damaged or missing parts, please call 1-800-543-6400 for customer assistance or call the nearest Campbell Hausfeld Authorized Service Center.

A listing of service center locations is enclosed. Have the serial number, model number, and parts list (with missing parts circled) before calling.

STOP! DO NOT RETURN THE PRODUCT TO THE RETAILER!



Record the Model No., Serial No. and date of purchase located on the base below the pump in the space below.

Model No. _____

Serial No. _____

Date of purchase _____

Retain these numbers for future reference.

⚠WARNING ***Do not operate unit if damaged during shipping, handling or use. Damage may result in bursting and cause injury or property damage.***

General Safety Information

Since the air compressor and other components (material pump, spray guns, filters, lubricators, hoses, etc.) used, make up a high pressure pumping system, the following safety precautions must be observed at all times:

1. Read all manuals included with this product carefully. Be thoroughly familiar with the controls and the proper use of the equipment.

2. Follow all local electrical and safety codes as well as in the US, National Electrical Codes (NEC) and Occupational Safety and Health Act (OSHA).

⚠DANGER

Breathable Air Warning

This compressor/pump is not equipped and should not be used "as is" to supply breathing quality air. For any application of air for human consumption, the air compressor/pump will need to be fitted with suitable in-line safety and alarm equipment. This additional equipment is necessary to properly filter and purify the air to meet minimal specifications for Grade D breathing as described in Compressed Gas Association Commodity Specification G 7.1 - 1966, OSHA 29 CFR 1910. 134, and/or Canadian Standards Associations (CSA).

DISCLAIMER OF WARRANTIES
In the event the compressor is used for the purpose of breathing air application and proper in-line safety and alarm equipment is not simultaneously used, existing warranties shall be voided, and Campbell Hausfeld disclaims any liability whatsoever for any loss, personal injury or damage.

© 2000 Campbell Hausfeld

General Safety Information (Continued)

3. Only persons well acquainted with these rules of safe operation should be allowed to use the compressor.
4. Keep visitors away and NEVER allow children in the work area.
5. Wear safety glasses and use hearing protection when operating the pump or unit.
6. Do not stand on or use the pump or unit as a handhold.
7. Before each use, inspect compressed air system and electrical components for signs of damage, deterioration, weakness or leakage. Repair or replace defective items before using.
8. Check all fasteners at frequent intervals for proper tightness.

⚠WARNING

Motors, electrical equipment and controls can cause electrical arcs that will ignite a flammable gas or vapor. Never operate or repair in or near a flammable gas or vapor. Never store or spray flammable liquids or gases in the vicinity of the compressor.

⚠CAUTION

Compressor parts may be hot even if the unit is stopped.

9. Keep fingers away from a running compressor; fast moving and hot parts will cause injury and/or burns.
10. If the equipment should start to abnormally vibrate, STOP the engine/motor and check immediately for the cause. Vibration is generally a warning of trouble.
11. To reduce fire hazard, keep engine/motor exterior free of oil, solvent, or excessive grease.

⚠WARNING ***Never remove or attempt to adjust safety valve. Keep safety valve free from paint and other accumulations.***

⚠DANGER

Never attempt to repair or modify a tank!

Welding, drilling or any other modification will weaken the tank resulting in damage from rupture or explosion. Always replace worn or damaged tanks.

⚠NOTICE ***Drain liquid from tank daily.***

13. Tanks rust from moisture build-up, which weakens the tank. Make sure to drain tank regularly and inspect periodically for unsafe conditions such as rust formation and corrosion.
14. Fast moving air will stir up dust and debris which may be harmful. Release air slowly when draining moisture or depressurizing the compressor system.

SPRAYING PRECAUTIONS

⚠WARNING

Do not spray flammable materials in vicinity of open flame or near ignition sources including the compressor unit.

15. Do not smoke when spraying paint, insecticides, or other flammable substances.
16. Use a face mask/ respirator when spraying and spray in a well ventilated area to prevent health and fire hazards.

17. Do not direct paint or other sprayed material at the compressor. Locate compressor as far away from the spraying area as possible to minimize overspray accumulation on the compressor.
18. When spraying or cleaning with solvents or toxic chemicals, follow the instructions provided by the chemical manufacturer.

Assembly

HANDLE ASSEMBLY

Compressor handle has a notch (or detent) at top of handle. This notch provides a handy place to hang a spray gun, sandblast gun, or other tool equipped with a hook.

1. If a handle grip was included with the unit, coat the inside of grip with a thin film of soapy water. Push grip onto handle.
2. Insert handle through shroud and into baseplate as shown in Figure 1. Handle must fit into special openings in baseplate.
3. Place a short piece of wood against end of handle and tap it with a mallet or hammer to drive handle into baseplate until hole in handle and baseplate line up.



Figure 1

4. Assemble and tighten 2 screws (from parts package) through hole in base-plate ensuring it goes through handle.

⚠WARNING ***Never use the handle to lift the unit completely off the ground. Only use the handle to lift one end so the wheels may be used to move the unit.***

5. Insert threaded post of rubber foot into hole in ground iron. Tighten securely with locknut.

WHEEL ASSEMBLY

The items marked with an asterisk (*) are included in parts package.

1. Insert shoulder bolt through wheel hub. The bolt hex head should be on the opposite side of protruding hub center.
2. For 6 - 8 inch diameter wheels, feed the shoulder bolt through the bottom hole on the tank axle iron and tightly secure with the locknut.



Figure 2 - Wheel Assembly

Assembly (Con't)

For 10 inch diameter wheels, feed the shoulder bolt through the top hole on the tank axle iron and tightly secure with the locknut. Repeat on the opposite side.

3. When assembled, the tank must sit level or slope slightly towards the drain cock to allow the tank to drain properly.

Installation

LOCATION

It is extremely important to install the compressor in a clean, well ventilated area where the surrounding air temperature will not be more than 100°F.

A minimum clearance of 18 inches between the compressor and a wall is required because objects could obstruct air flow.

⚠CAUTION ***Do not locate the compressor air inlet near steam, paint spray, sandblast areas or any other source of contamination. This debris will damage the motor.***

ELECTRICAL INSTALLATION

⚠WARNING ***All wiring and electrical connections should be performed by a qualified electrician. Installation must be in accordance with local codes and national electrical codes.***

⚠CAUTION

Never use an extension cord with this product. Use additional air hose instead of an extension cord to avoid power loss and permanent motor damage. Use of an extension cord voids the warranty.

GROUNDING INSTRUCTIONS

1. This product is for use on a nominal 120 volt circuit and has a grounding plug that looks like the plug illustrated in Fig. 3. Make sure the product is connected to an outlet having the same configuration as the plug. This product must be grounded. In the event of an electrical short circuit, grounding reduces risk of electrical shock by providing an escape wire for electric current. This product is equipped with a cord having a grounding wire with an appropriate grounding plug. Plug must be plugged into an outlet that is properly installed and grounded in accordance with all local codes and ordinances.



Figure 3 - Grounding Method

⚠DANGER

Improper use of grounding plug can result in a possible risk of electrical shock!

⚠DANGER ***Do not use a grounding adapter with this product!***

2. If repair or replacement of cord or plug is necessary, do not connect grounding wire to either flat blade terminal. The wire with insulation having an external surface that is green (with or without yellow stripes) is the grounding wire.

⚠WARNING ***Never connect green (or green and yellow) wire to a live terminal.***

3. Check with a qualified electrician or serviceman if grounding instructions are not completely understood, or if in doubt as to whether product is properly grounded. Do not modify plug provided; if it will not fit outlet, have proper outlet installed by a qualified electrician.

WIRING

1. Local electrical wiring codes differ from area to area. Source wiring, plug and protector must be rated for at least the amperage and voltage indicated on motor nameplate, and meet all electrical codes for this minimum.
2. Use a slow blow fuse or a circuit breaker.

⚠CAUTION ***Overheating, short circuiting and fire damage will result from inadequate wiring, etc.***

NOTE: 120 volt, 15 amp units can be operated on a 120 volt circuit under the following conditions:

a. No other electrical appliances or lights are connected to the same branch circuit.
b. Voltage supply is normal.
c. Circuit is equipped with a 15 amp circuit breaker or a 15 amp slow blow fuse.

3. If these conditions cannot be met or if nuisance tripping of current protection device occurs, it may be necessary to operate compressor from a 120 volt, 20 amp circuit.

Operation



Figure 4

Pressure Switch - Auto/Off Switch - In the **ON** position, the compressor shuts off automatically when tank pressure reaches the maximum preset pressure. The compressor will automaticallly restart when it reaches the minimum preset pressure. In the **OFF** position, the compressor will not operate. This switch should be in the **OFF** position when connecting or disconnecting the power cord from the electrical outlet or when changing air tools.

Regulator - The regulator controls the amount of air pressure released at the hose outlet.

ASME Safety Valve - This valve automatically releases air if the tank pressure exceeds the preset maximum.

Handle - Designed to move the compressor.

Tool Storage - 1/4 inch quick connect couplers fit in holes to support air chuck and other inflation fittings.

Operation (Continued)

⚠WARNING ***Never use the handle on wheeled units to lift the unit completely off the ground.***

Drain Petcock - This valve is located on the bottom of the tank. Use this valve to drain moisture from the tank daily to reduce the risk of corrosion.

Reduce tank pressure below 10 PSI, then drain moisture from tank daily to avoid tank corrosion. Drain moisture from tank(s) by opening the drain petcock located underneath the tank.

LUBRICATION

This is an oilless product and **DOES NOT** require lubrication to operate.

BREAK-IN PROCEDURE

⚠CAUTION ***Do not attach air chuck or other tool to open end of hose until start-up has been completed and unit checks OK.***

IMPORTANT: Do not operate compressor before reading instructions or damage may result.

1. Turn regulator fully clockwise to open air flow.
2. Turn switch to OFF position and plug in power cord.



Figure 5

3. Turn switch to ON position and run unit for 15 minutes to break in the pump parts.



Figure 6

4. Turn regulator knob fully counterclockwise. Compressor will build to maximum preset pressure and shut off.
5. Turn regulator knob clockwise to cause air to bleed off. Compressor will restart at a preset pressure.
6. Turn regulator knob counterclockwise to shut off the air and turn switch to Off position.
7. Attach chuck or other tool to open end of hose. Turn the regulator clockwise and set tool pressure to proper level.

MOISTURE IN COMPRESSED AIR

Moisture in compressed air will form into droplets as it comes from an air compressor pump. When humidity is high or when a compressor is in continuous use for an extended period of time, this moisture will collect in the tank. When using a paint spray or sandblast gun, this water will be carried from the tank through the hose, and out of the gun as droplets mixed with the spray material.

IMPORTANT: This condensation will cause water spots in a paint job, especially when spraying other than water based paints. If sandblasting, it will cause the sand to cake and clog the gun, rendering it ineffective. A filter in the air line (MP3105), located as near to the gun as possible, will help eliminate this moisture.

In the ON position, the compressor pumps air into the tank. It shuts off automatically when unit reaches its maximum preset pressure. In the OFF position, the compressor will not operate. This switch should be in the OFF position when connecting or disconnecting the power cord from the electrical outlet.

ASME SAFETY VALVE

⚠WARNING ***Do not remove or attempt to adjust the safety valve!***

This valve should be checked under pressure occasionally by pulling the ring by hand. If air leaks after ring has been released, or valve is stuck and cannot be actuated by ring, it MUST be replaced.

Figure 7

REGULATOR KNOB

1. This knob controls air pressure to an air operated tool, or paint spray gun.
2. Turning knob clockwise increases air pressure at outlet.
3. Turning counterclockwise will lower air pressure at outlet.
4. Fully counterclockwise will shut off flow of air completely.

OUTLET (TOOL) PRESSURE GAUGE

1. This gauge shows at-a-glance, air pressure at outlet. Air pressure is measured in pounds per square inch (psi).
2. Be sure this gauge reads ZERO before changing air tools or disconnecting hose from outlet.

TANK PRESSURE GAUGE

Gauge shows pressure in tank indicating compressor is building pressure properly.

Maintenance

⚠WARNING

Disconnect power source then release all pressure from the system before attempting to install, service, relocate or perform any maintenance.

The compressor should be checked often for any visible problems and the following maintenance procedures should be performed each time the compressor is used.

1. Pull ring on safety valve and allow it to snap back to normal position.

⚠WARNING ***Safety valve must be replaced if it cannot be actuated or it leaks air after ring is released.***

2. With compressor shut off and pressure released: Drain moisture from tank by opening drain cock underneath tank.



Figure 8

3. Turn power OFF and clean dust and dirt from pump cover, tank and air lines.

IMPORTANT: Unit should be located as far from spraying area as hose will allow to prevent over-spray from clogging filter.

LUBRICATION

This is an oilless type compressor requiring no lubrication.

STORAGE

1. When not in use, hose and compressor should be stored in a cool dry place.
2. Tank should be drained of moisture.
3. Hose should be disconnected and hung open ends down, to allow any moisture to drain.

Notes

Oilless Compressors

Troubleshooting Chart

Symptom	Possible Cause(s)	Corrective Action
Compressor will not run	1. No electrical power 2. Blown fuse 3. Breaker open 4. Pressure switch bad 5. Check valve defective	1. Plugged in? Check fuse/breaker or motor overload 2. Replace blown fuse 3. Reset, determine cause of problem 4. Replace 5. Remove and replace check valve **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***
Motor hums but cannot run or runs slowly	1. Poor contacts, line voltage incorrect 2. Shorted or open motor winding 3. Defective check valve or unloader	1. Check connections, check with voltmeter 2. Replace motor 3. Replace or repair **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***
Fuses blow/circuit breaker trips repeatedly **⚠CAUTION** ***Never use an extension cord with this product***	1. Incorrect size fuse, circuit overloaded 2. Defective check valve or unloader	1. Check for proper fuse, use time-delay fuse. Disconnect other electrical appliances from circuit or operate compressor on its own branch circuit 2. Replace or repair **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***
Tank pressure drops when compressor shuts off	1. Loose connections (fittings, tubing, etc.) 2. Loose drain cock 3. Check valve leaking	1. Check all connections with soap and water solution and tighten 2. Tighten 3. Disassemble check valve assembly, clean or replace **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***
Air output lower than normal/low discharge pressure	1. Air leaks in piping (on machine or in outside system) 2. Piston ring broken	1. Replace leaking components or tighten as necessary 2. Replace

Troubleshooting Chart (Continued)

Symptom	Possible Cause(s)	Corrective Action
Excessive moisture in discharge air	1. Excessive water in tank 2. High humidity	1. Drain tank 2. Move to area of less humidity; use air line filter
Compressor runs continuously	1. Defective pressure switch 2. Excessive air usage	1. Replace switch 2. Decrease air usage; compressor not large enough for air requirement
Excessive starting and stopping (auto start)	1. Excessive condensation in tank 2. Air leaks in piping (on machine or in outside system) 3. Tank check valve leaking	1. Drain more often 2. Replace leaking components or tighten as necessary 3. Replace or repair as necessary **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***
Air leaking from unloader on pressure switch	Check valve stuck in an open position	Remove and replace check valve **⚠DANGER** ***Do not disassemble check valve with air in tank; bleed tank***

Limited Warranty

1. DURATION: From the date of purchase by the original purchaser as follows: Standard Duty - One Year, Serious Duty - Two Years, Extreme Duty - Three Years.
2. WHO GIVES THIS WARRANTY (WARRANTOR):
   Campbell Hausfeld / Scott Fetzer Company, 100 Production Drive, Harrison, Ohio, 45030, Telephone: (800) 543-6400
3. WHO RECEIVES THIS WARRANTY (PURCHASER): The original purchaser (other than for purposes of resale) of the Campbell Hausfeld compressor.
4. WHAT PRODUCTS ARE COVERED BY THIS WARRANTY: Any Campbell Hausfeld air compressor.
5. WHAT IS COVERED UNDER THIS WARRANTY: Substantial defects due to material and workmanship with the exceptions noted below.
6. WHAT IS NOT COVERED UNDER THIS WARRANTY:
   A. Implied warranties, including those of merchantability and FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED FROM THE DATE OF ORIGINAL PURCHASE AS STATED IN THE DURATION. If this compressor is used for commercial, industrial or rental purposes, the warranty will apply for ninety (90) days from the date of purchase. Four cylinder single-stage and two-stage compressors are not limited to a ninety (90) day warranty when used in commercial or industrial applications. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
   B. ANY INCIDENTAL, INDIRECT, OR CONSEQUENTIAL LOSS, DAMAGE, OR EXPENSE THAT MAY RESULT FROM ANY DEFECT, FAILURE, OR MALFUNCTION OF THE CAMPBELL HAUSFELD PRODUCT. Some States do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
   C. Any failure that results from an accident, purchaser's abuse, neglect or failure to operate products in accordance with instructions provided in the owner's manual(s) supplied with compressor.
   D. Pre-delivery service, i.e. assembly, oil or lubricants, and adjustment.
   E. Items or service that are normally required to maintain the product, i.e. lubricants, filters and gaskets, etc.
   F. Gasoline engines and components are expressly excluded from coverage under this limited warranty. The Purchaser must comply with the warranty given by the engine manufacturer which is supplied with the product.
   G. Additional items not covered under this warranty:
      1. All Compressors
         a. Any component damaged in shipment or any failure caused by installing or operating unit under conditions not in accordance with installation and operation guidelines or damaged by contact with tools or surroundings.
         b. Pump or valve failure caused by rain, excessive humidity, corrosive environments or other contaminants.
         c. Cosmetic defects that do not interfere with compressor functionality.
         d. Rusted tanks, including but not limited to rust due to improper drainage or corrosive environments.
         e. Electric motors, check valves and pressure switches after the first year of ownership.
         f. Drain cocks.
         g. Damage due to incorrect voltage or improper wiring.
         h. Other items not listed but considered general wear parts.
         i. Pressure switches, air governors and safety valves modified from factory settings.
      2. Lubricated Compressors
         a. Pump wear or valve damage caused by using oil not specified.
         b. Pump wear or valve damage caused by any oil contamination or by failure to follow proper oil maintenance guidelines.
      3. Belt Drive / Direct Drive / Gas Driven Compressors
         a. Belts.
         b. Ring wear or valve damage from inadequate filter maintenance.
         c. Manually adjusted load/unload and throttle control devices.
7. RESPONSIBILITIES OF WARRANTOR UNDER THIS WARRANTY: Repair or replace, at Warrantor's option, compressor or component which is defective, has malfunctioned and/or failed to conform within duration of the warranty period.
8. RESPONSIBILITIES OF PURCHASER UNDER THIS WARRANTY:
   A. Provide dated proof of purchase and maintenance records.
   B. Portable compressors or components must be delivered or shipped to the nearest Campbell Hausfeld Authorized Service Center. Freight costs, if any, must be borne by the purchaser.
   C. Use reasonable care in the operation and maintenance of the products as described in the owner's manual(s).
9. WHEN WARRANTOR WILL PERFORM REPAIR OR REPLACEMENT UNDER THIS WARRANTY:
   A. Repair or replacement will be scheduled and serviced according to the normal work flow at the servicing location, and depending on the availability of replacement parts.
   B. If the purchaser does not receive satisfactory results from the Authorized Service Center, the purchaser should contact Campbell Hausfeld (see paragraph 2).

Limited Warranty applies in the U.S. and Canada only and gives you specific legal rights. You may also have other rights which vary from State to State or country to country.

CAMPBELL HAUSFELD
BUILT TO LAST

Oilless Single Cylinder Pump
Pompe Monocylindrique Sans Huile
Bomba De Un Cilindro Sin Aceite

Replacement Parts List
Liste de Pièces de Rechange
Lista de Repuestos

WL390000

For parts, products & service information visit
POWER XPERT
www.campbellhausfeld.com



@ 2000 Campbell Hausfeld

Replacement Parts List
Liste de Pièces de Rechange
Lista de Repuestos

WL390000

For Replacement Parts, Call 1-800-543-6400
Pour Pièces de Rechange, Composer le 1-800-543-6400
Para Ordenar Repuestos, Sírvase Llamar al Distribuidor más Cercano a su Domicilio

Please provide the following information:
-Model number
-Serial number (if any)
-Part description and number as shown in parts list

S'il vous plait fournir l'information suivante:
-Numéro du modèle
-Numéro de série (s'il y en a un)
-Description de la pièce et son numéro sur la liste

Sírvase darnos la siguiente información:
-Número del modelo
-Número de serie (de haberlo)
-Descripción y número del repuesto según la lista de repuestos

Address parts correspondence to:
Correspondance:
Puede escribirnos a:
The Campbell Group
Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 USA

Ref. No. Nº. de Réf. No. de Ref.		Description Description Description	Part Number Numéro de Pièce Número de Pieza	Qty. Qté. Ctd.
1		Pump/motor assembly (with belt) Montage de pompe/moteur (avec courroie) Conjunto bomba/motor (con correa)	WL210900AJ	1
2	▲	Cylinder gasket Joint d'étanchéité de cylindre Empaque del cilindro	XA012400AV	1
3		Intake valve Soupape d'admission Válvula de entrada	▲	1
4		Valve plate Plaque de soupape Placa de la válvula	▲	1
5		Exhaust valve Soupape d'échappement Válvula de salida	▲	1
6	▲	Head gasket Joint d'étanchéité de culasse Empaque de la culata	XA010800AV	1
7	▲	Exhaust valve gasket Joint de soupape d'échappement Empaque de la válvula de salida	XA012500AV	1
8		Head Culasse Culata	WL010500AV	1
9		Piston assembly (Includes #10) Montage de piston (#10 compris) Ensamblaje de pistón (Incluye #10)	WL211000AJ	1
10		3/8" Flat head screw Vis à tête plate de 3/8 po Tornillo de cabeza plana de 9,5 mm (3/8")	ST071802AV	1
11	●	1/4"-20 x 4" Hex. head cap screw Vis a tete hex. de 1/4 po-20 x 4 po Tornillo hex. de 6,4 mm (1/4")-20 x 10,16 cm (4")	ST074319AV	4
12		Fan Ventilateur Ventilador	WL008400AV	1
13	▲	Muffler Silencieux Silenciador	WL011100AV	1
14		Compression connector Raccord de compression Conector de compresión	ST159001AV	1
REPLACEMENT PARTS KITS - JEUX DE PIÈCES DE RECHANGE - KIT DE PIEZAS DE REPUESTO				
●		Head bolt kit (Set of 4 ea., part #11) Jeu de boulons à tête (4 chaque, pièce #11) Kit de prisioneros (Juego de 4 cada uno., pieza #11)	WL211100AJ	1
▲		Valve plate kit (Includes #2-7, 13) Jeu de plaque de soupape (#2-7, 13 compris) Kit de placa de válvula (Incluye #2-7, 13)	WL211200AJ	1

IMPORTANT

DO NOT RETURN TO STORE

Call us first at 1-800-543-6400

All Campbell Hausfeld products are engineered and tested to work "First Time Every Time." However, in the event you encounter product difficulty or require assistance, please call us at the toll-free number shown. We'll direct you to one of Campbell Hausfeld's 900 service centers in the United States. If local service is not available, you may be instructed to ship the product **with a copy of the original purchase receipt** to a regional service center.

If unable to obtain service through our toll-free number, you may return product to the place of purchase in accordance with store return policy.

Thank you for your interest in Campbell Hausfeld products.

⚠ NOTICE ***It is the consumer's responsibility to drain all oil and gasoline prior to shipment to meet ICC, state and local fire regulations***

⚠ NOTICE ***To avoid power loss and overheating, and ensure easier starting, use additional air hose rather than extension cords***

For parts, products & service information visit
POWER XPERT
www.campbellhausfeld.com

IN177800AV 1/99